

Application Note: Flex DP Upgrades November 2011

Included Files:

PodWare_V5.68.0_Beta
DspNetPlus_2003V1080
TFA600HWDpv4 Beta
TFA600HDPv6 Beta

Parts needed:

2 x 4k7 1/4w resistors

Process:

The amplifier must be removed from the unit, by removing the rear flygear, and taking out the metal panel.

The Input card must be removed from the metal panel by removing the small posi-drive screws from the XLR connectors on the front side of the metal panel, and removing the two wiring looms from the PCB.

Two 4k7 1/4w resistors should be soldered into holes R9 and R10 on the PCB.

The unit can now be reassembled.

On the computer, install the new version of Podware (5.68)

Update the firmware of the cabinet to 2003V1080

Then load the new settings file dependant on the horn flare of the cabinet.